


P-Ecke Bochum ohne Armlehnen

- 
 - (DE) Montageanleitung
 - (PL) Instrukcja montażu
 - (NL) Handleiding voor de montage
 - (GB) Assembly instructions
 - (TR) Montaj talimatı
 - (RU) Инструкция по монтажу
- (IT) Istruzioni di montaggio
 - (FR) Notice de montage
 - (RO) Instrucțiuni de asamblare
 - (SK) Montážny návod
 - (CZ) Montážní návod
 - (HU) Szerelési útmutató










Service - Servis - Dienstverlening - Servis - Сервис - Служба - Servizio - Service
Serviciu - Služby - Szolgáltatás









Name - Nazwa - Naam - Name - Isim - название
Nome - Nom - Numele - Meno - Jméno - Neve

P-Ecke Bochum ohne Armlehnen



1:L

| | | | | | | | | |
|---|---|---|---|--|---|--|--|---|
| 4 x (8x70)  | 4 x Ø8  | 4 x M8  | 9 x (4x16)  | 10 x 50mm  | 4 x (5x50)  | 6 x (M6x35)  | 2 x 32 cm  | 3 x 57 cm  |
| a | b | c | d | W | t | e | 1 | 2 |



P-Ecke Bochum ohne Armlehnen



- DE

Montageanleitung
- PL

Instrukcja montażu
- NL

Handleiding voor de montage
- GB

Assembly instructions
- TR

Montaj talimatı
- RU

Инструкция по монтажу

IT

Istruzioni di montaggio

FR

Notice de montage

RO

Instrucțiuni de asamblare

SK

Montážny návod

CZ

Montážní návod

HU


Szerelési útmutató

Service - Servis - Dienstverlening - Servis - Servis - Сервисная служба - Servizio - Service
Serviciu - Služby - Szolgáltatás

Name - Nazwa - Naam - Name - Isim - название
Nome - Nom - Numele - Meno - Jméno - Neve

P-Ecke Bochum ohne Armlehnen

2:P



| | | | | | | |
|------------------|------------|------------|----------------|------------------|-------------------|-----------------|
| 4 x (8x70) | 4 x Ø8 | 4 x M8 | 9 x (4x16) | 10 x 50mm | 4 x (5x50) | 6 x (M6x35) |
| | | | | | 2 x 56 cm 1 | |
| | | | | | 3 x 57cm 2 | |

